


U1 Ultra

Thank you for purchasing this Oknife product. Please read this manual carefully before use and keep it for future reference!

PARTS DESCRIPTION




SPECIFICATIONS

Handle Material	Titanium/0-Aluminium
Blade Material	Ceramic
Weight	83.5g/2.95oz(Titanium) 64g/2.26oz(0-Aluminium)
Dimensions	85.9x33.3x15.2mm 3.38x1.08x0.44in

01


HOW TO USE OPEN THE KNIFE

To open the knife when it's locked, use the thumb stud or flipper for quick deployment




LOCK

Once the knife is fully opened, the button lock will automatically engage, securing the blade in place.



CLOSE THE KNIFE


To close the knife, manually press the button lock to unlock the knife first, then push the blade holder approximately 180° to close the blade.



02


BLADE UNLOCKING

To unlock the blade, loosen the locking screw and open the blade holder cover



BLADE REPLACEMENT

After fully unlocking the blade, gently pull it out to remove it. Align the new blade with the slot on the handle and insert it into the designated position. Tighten the locking screw to complete the blade replacement.



03

⚠ DANGER

- Keep out of reach of children. DO NOT let your children play with this knife to prevent injuries.
- This blade is very sharp. Improper use may cause injuries.

WARNING

- Make sure the blade is fully retracted and locked when storing or carrying the knife.
- DO NOT use the knife to cut hard objects such as metals and rocks, as this may cause the blade to chip or break.
- When replacing or reinstalling the blade, please ensure that the blade is inserted fully into the blade holder (as shown below) and tighten the screw to secure it in place.

Once the blade is properly installed, the back spine of the blade should not extend beyond the blade holder.



- This knife is NOT intended for food preparation.

NOTICE

- The knife blade may lose its sharpness over time. You can replace it with a new blade (not included) when necessary.
- Clean the knife and wipe it dry immediately after use. Apply oil to the blade to prevent rust if the knife is left unused for a long period of time. Store in a dry place.

04

WARRANTY

Your Oknife Utility knife Series products are guaranteed against defects in material and workmanship and have a limited lifetime warranty to the original purchaser of the products.

-Oknife Utility knife Series Team will not warranty products due to loss, damage caused by abuse, neglect, misuse, or accident.

-Repairs to your product performed by any source other than Oknife Utility knife Series Team unconditionally voids the knife's warranty.

-Cost for postage is the responsibility of the customer.

Official Website
www.oknife.com

USA Customer Support
cs@oknife.com

Shenzhen Aodao Technology Co., Ltd
Room 1601, Building 1B, Yuefu Plaza, Guangming District, Shenzhen City, Guangdong, China

05